Commercial Work Table Assembly Instructions for K.D. Equipment



1 Let the tabletop upside down on a soft cloth to prevent scratches. Insert one pipe into tabletop leg sockets



Remove the allen screws and the wrench



3. After securing three pipes, position under shelf 6 inches or more above the ground.



4. Slide the last pipe.



5. Each corner support requires two allen screws. Wait until the table is completely assembled before tightening each allen screw.



6. All four pipes can be adjusted for the surface that are not completely level. Rotate the plastic foot pad for differences in floor surface.



7. Turn the table over after each screw is securely tightened.

Two people should be required to rotate the table.